








Short manual

- a) Push  , the display shows "CL6". If not, than push  to go to "CL6".
- b) Fill the bottle with 10 ml (to the dash) of the liquid to be calibrated and tighten the lid. And dry the bottle on the outside.
- c) Place the bottle in the meter with the arrow on the bottle and the arrow on the meter towards each other  , and press the rubber ring around the lid so that no light can get underneath.
- d) Push  and wait until the display shows 0.00.
- e) Now add 1 tablet DPD1 to the bottle, crush the tablet with the supplied plastic stamper, close the bottle with the lid and gently shake the bottle. The liquid will now turn pink.
- f) Put the bottle back within 20 seconds, as described in step c).
- g) Push  and wait until the meter indicates a value. This is the value of the free chlorine.
- h) Now add 1 tablet DPD3 to the bottle with tablet DPD1, disrupt the tablet, close the bottle and put it back in the same way as in step c).
- i) Keep the button  pressed and at the same time press the button  and then release both buttons.
- j) The meter will now count down for 2 minutes, and then indicates the value of the total chlorine.
- k) Clean everything after use!**

